



## Waveform generator update to the latest firmware

The function generator's firmware can be updated via the flash drive. This process takes about two minutes. Follow the next steps:

1. Insert the USB flash drive containing the new firmware to USB host interface on the front panel of the generator.
2. Press the **Utility** button to enter the **Utility Menu**.
3. Press **1/2↓** option button to enter the second page of **Utility Menu**.
4. Press the **Update** option button.
5. Press **Browser** option button to select **Directory**, and then select the **USB Device (A :)** through direction key.
6. Press **Browser** option button to select **File**, and then select the **XXXX.ADS** file by direction key.
7. Press the **Recall** option button to updating.
8. After performing the update, restart the generator.

**Note:** Do not turn off the unit's power while the firmware is being updated.