



SDG7000A Update Instructions

Notes: During the updating, do not cut off the power or pull out the U-disk

1. Please firstly copy the update file (.ADS) to U-disk.
2. Insert the U-disk to the USB port.
3. Press the **UTILITY** button to enter the system setting interface.



4. Press **Update** button to enter the file system. Select the right update firmware (.ADS).
5. Press **Recall** button. The upgrade progress bar will be displayed on the system interface. After the firmware upgrade is complete, the system will automatically reboot.



6. After the signal source is rebooted, press the **UTILITY** button and select the **System Information** to see if the firmware update successfully.

System Info	
Startup Times:	107
Software Version:	1.1.1.29R8