

## Firmware Update Instructions

**Notes:** 1. During the updating, do not cut off the power or pull out the U-disk

2. If your analyzer has an earlier version, please update to V3.2.2.4.0 first and then proceed to update to the latest version.

1. Please firstly copy the update file (.ADS) to U-disk.
2. Insert the U-disk to the USB port.
3. Press **Menu** button and then press **System**, and press **Service**, we can enter **Service** interface.






Figure 1 System menu

4. Press **Upgrade** and then enter the file system. Use the knob or touch screen to select the right update firmware. Then press **OK**, we will see an information window. Press the **Yes** and will see the upgrading information ('hourglass and Please do not power off or unplug your machine. Installing update ...') This upgrade program will take about 2~3 minutes.






Figure 2 Update interface

- When the device upgrading finished, it will restart by itself. We can check the version information in system info(Menu--System--Utilities--About).



Figure 3 System info