

SDS2000X Firmware Update Instructions

Note: during the updating, do not turn off the power or pull out the U-disk.

1. First, unzip the firmware file (.ads) in the update package to a U-disk (thumb drive).
2. Insert the U-disk into the USB port on the front of the oscilloscope.
3. Press **Utility** and then **Next Page** to get to the third page of the UTILITY function menu.




Figure 1 UTILITY function menu

4. Press **Update** and then choose **Firmware** to enter the file system.




Figure 2 File system

5. Use the universal knob to select the new update firmware, which will be the .ads file, and then press the Press To Update softkey. Next press the Single button to start the upgrade program. The program will take approximately 5-6 minutes to load.
6. After seeing the prompt, "Update Success! Please Restart the SPO," please restart the oscilloscope.




Figure 3 Update successfully

Note: during the updating, do not turn off the power or pull out the U-disk.