

Configuring the IP address on the SDS1000 (DL+, CNL+, and more)

December 03, 2018

To adjust the IP settings on the SDS1000 series, including the SDS1052DL+:

- Press Utility > Next Page to page 3/4:



- Press the softkey next to IO Setting > Press the softkey next to IP Setting:



- Now, you can see the IP configuration. Press the topmost softkey (shown below) to step through each parameter and use the Intensity Knob to adjust each value:





North American Headquarters

SIGLENT Technologies NA
6557 Cochran Rd Solon, Ohio 44139
Tel: 440-398-5800
Toll Free: 877-515-5551
Fax: 440-399-1211
info@siglent.com
www.siglentamerica.com/

European Sales Offices

SIGLENT TECHNOLOGIES GERMANY GmbH
Staetzlinger Str. 70
86165 Augsburg, Germany
Tel: +49(0)-821-666 0 111 0
Fax: +49(0)-821-666 0 111 22
info-eu@siglent.com
www.siglenteu.com

Asian Headquarters

SIGLENT TECHNOLOGIES CO., LTD.
Blog No.4 & No.5, Antongda Industrial Zone,
3rd Liuxian Road, Bao'an District,
Shenzhen, 518101, China.
Tel: + 86 755 3661 5186
Fax: + 86 755 3359 1582
sales@siglent.com
www.siglent.com/ens