

Oscilloscope Hardware Reset

October 25, 2017

In some extreme hardware errors, the oscilloscope may become unresponsive or "hang" during the boot sequence.

If your oscilloscope is frozen, will not boot, or appears to be unresponsive, you can attempt a hardware reset by following these instructions:

- 1. Disconnect all USB, LAN, and input cables. Leave the power cord connected.
- 2. Power cycle the instrument by pressing the power button.
- 3. Immediately begin pressing the MATH button repeatedly at a rate of 2 to 3 times a second while the instrument boots up.
- 4. If the instrument does not boot up properly, retry steps 2 through 4.

NOTE: If you continue to have problems, contact your nearest SIGLENT office for service.



North American Headquarters

SIGLENT Technologies NA 6557 Cochran Rd Solon, Ohio 44139 Tel: 440-398-5800

Toll Free:877-515-5551 Fax: 440-399-1211 info@siglentna.com www.siglentna.com

European Sales Offices

SIGLENT TECHNOLOGIES GERMANY GmbH Liebigstrasse 2-20, Gebaeude 14, 22113 Hamburg Germany

Tel: +49(0)40-819-95946 Fax: +49(0)40-819-95947 info-eu@siglent.com www.siglenteu.com

Asian Headquarters

SIGLENT TECHNOLOGIES CO., LTD.
Blog No.4 & No.5, Antongda Industrial Zone,
3rd Liuxian Road, Bao'an District,
Shenzhen, 518101, China.
Tel:+ 86 755 3688 7876
Fax:+ 86 755 3359 1582

sales@siglent.com
www.int.siglent.com