


# How to quickly save a picture with SIGLENT SDS Oscilloscopes

October 25, 2017

Many SIGLENT scopes feature a quick print key located on the front panel.


To save a copy of the display image as a bitmap file (BMP):

1. Verify that the Print key is assigned to the save to USB. This is indicated by an “S” located at the top of the display:




If the scope indicates “P”, then you will need to reconfigure the print button.

2. Insert a USB memory device into the USB port located on the front panel of the scope
3. Press the Print button located on the front panel:




## Configuring The Print Button


1. Press Utility
2. Press “Next Page” until you get to page 2/4
3. Select Print Setup



4. Set Print Key to “Save Picture”



5. Press Menu Off to get back to the main display





### **North American Headquarters**

SIGLENT Technologies NA  
6557 Cochran Rd Solon, Ohio 44139  
Tel: 440-398-5800  
Toll Free: 877-515-5551  
Fax: 440-399-1211  
[info@siglent.com](mailto:info@siglent.com)  
[www.siglentamerica.com/](http://www.siglentamerica.com/)

### **European Sales Offices**

SIGLENT TECHNOLOGIES GERMANY GmbH  
Staetzlinger Str. 70  
86165 Augsburg, Germany  
Tel: +49(0)-821-666 0 111 0  
Fax: +49(0)-821-666 0 111 22  
[info-eu@siglent.com](mailto:info-eu@siglent.com)  
[www.siglenteu.com](http://www.siglenteu.com)

### **Asian Headquarters**

SIGLENT TECHNOLOGIES CO., LTD.  
Blog No.4 & No.5, Antongda Industrial Zone,  
3rd Liuxian Road, Bao'an District,  
Shenzhen, 518101, China.  
Tel: + 86 755 3661 5186  
Fax: + 86 755 3359 1582  
[sales@siglent.com](mailto:sales@siglent.com)  
[www.siglent.com/ens](http://www.siglent.com/ens)