

How to save a full screen picture of the SHS display?

July 16, 2018

The SHS800 and SHS1000 series can save exact copies of the display images to an external USB memory device, but the normal save process can "cut off" the bottom.

The Normal Picture/Image Save Process:

- Insert compatible USB memory device into the scope
- Press Save/Recall
- Set Type = Picture
- Press Save

This will save an image similar to this:



As you can see, the menu is a blocking a fair portion of the display.

There is another method of saving the full screen.

- Insert compatible USB memory device into the scope
- Press and hold the Save/Recall button for 5 seconds (maybe a little longer)
- There will be a progress indicator on the display

SIGLENT[®]





North American Headquarters

SIGLENT Technologies NA 6557 Cochran Rd Solon, Ohio 44139 Tel: 440-398-5800 Toll Free:877-515-5551 Fax: 440-399-1211 info@siglent.com www.siglentamerica.com/

European Sales Offices

SIGLENT TECHNOLOGIES GERMANY GmbH Staetzlinger Str. 70 86165 Augsburg, Germany Tel: +49(0)-821-666 0 111 0 Fax: +49(0)-821-666 0 111 22 info-eu@siglent.com www.siglenteu.com

Asian Headquarters

SIGLENT TECHNOLOGIES CO., LTD. Blog No.4 & No.5, Antongda Industrial Zone, 3rd Liuxian Road, Bao'an District, Shenzhen, 518101, China. Tel:+ 86 755 3661 5186 Fax:+ 86 755 3359 1582 sales@siglent.com www.siglent.com/ens