

## How to install the USBTMC driver

October 24, 2017

SIGLENT Technologies uses a broad range of products that utilize the USBTMC unified protocol to communicate with the host computer and control. Users can use SIGLENT provided PC software to send commands to remotely control the instrument.

In addition, you can use NI-MAX (National Instruments Measurement and Automation Explorer) for instrument control.

Here is an example of using SIGLENT EasyScope Oscilloscope software via the USB interface for remote control:

1. Connect the oscilloscope to the controlling computer using a USB cable. The computer should notify you that a new USBTMC device has been connected. You can check the Device Manager (Windows OS) for more details.
2. Install the USB driver. The oscilloscope is a USBTMC device. If your PC has installed EasyScope software and NI software, the first time the oscilloscope and PC are connected correctly and turned on, the PC Hardware Update Wizard dialog box will pop up. Follow the prompts of the installation wizard "USB Test and Measurement Device" driver.

The steps are as follows:

- Check the "Specify the installation location (Advanced) (s) from the list."
- Click "Next"
- Check the "Do not search, I will choose the driver to install (D)."
- Click "Next" and "Next". The wizard is installing the software, please wait...

Click "Finish" to install the USBTMC driver successfully.



### **North American Headquarters**

SIGLENT Technologies NA  
6557 Cochran Rd Solon, Ohio 44139  
Tel: 440-398-5800  
Toll Free: 877-515-5551  
Fax: 440-399-1211  
[info@siglent.com](mailto:info@siglent.com)  
[www.siglentamerica.com/](http://www.siglentamerica.com/)

### **European Sales Offices**

SIGLENT TECHNOLOGIES GERMANY GmbH  
Staetzlinger Str. 70  
86165 Augsburg, Germany  
Tel: +49(0)-821-666 0 111 0  
Fax: +49(0)-821-666 0 111 22  
[info-eu@siglent.com](mailto:info-eu@siglent.com)  
[www.siglenteu.com](http://www.siglenteu.com)

### **Asian Headquarters**

SIGLENT TECHNOLOGIES CO., LTD.  
Blog No.4 & No.5, Antongda Industrial Zone,  
3rd Liuxian Road, Bao'an District,  
Shenzhen, 518101, China.  
Tel: + 86 755 3661 5186  
Fax: + 86 755 3359 1582  
[sales@siglent.com](mailto:sales@siglent.com)  
[www.siglent.com/ens](http://www.siglent.com/ens)