

How to save a file with the SSA3000X

October 25, 2017

The SSA3000X can save a number of file types to either internal memory or an external USB memory device.

Here are instructions on how to view and save files:

- If you intended to save to an external device, insert a USB memory device into the front panel USB slot.
- Press File located on the front panel:



- This will open the file dialog window, as shown below:

SIGLENT[°]

SIGLEN	т	2016-09-08 13:41	.:54	Ű	File
LOG 10 dB	File				Browser Dir File
	U-disk0:/				Open/Load
Free	Folder	File Name	Type Size	Date	
LgPwr Cont	local: free 80,42 MB +U-disk0: 16.00 KB/7.46 GB	System Volume Informa	folder 88 B	2016-09-08 13:43:12	Back
					View Type All Type
A C&W					Save Type JPG
P-PK					Save
					JPG
					Create Folder
					Operate 🕨
					Local

- Press the soft-key labeled Browser to select the directory that you wish to save to. Select local to save to the instrument memory or U-disk0 to save to the external USB memory device.

NOTE: You can also use the scroll wheel or Up/Down arrows to highlight selections.



SIGLENT[®]

- Press the View Type soft-key to filter the file extensions based on file type. If you would like to see all files, select All Type.

SIGLEN	ſ	2016-09-08 13:44	2:04		Ű	View Type
LOG 10 dB	File					All Type
	U-disk0:/					STA
Free	Folder	File Name	Туре	Size	Date	
LgPwr Cont	local: free 80.20 MB +U-disk0: 68.00 KB/7.46 GB	System Volume Informa SSA_160908134153.jpg	folder jpg	88 B 49.80 KB	2016-09-08 13:43:12 2016-09-08 13:41:55	TRC
						COR
A C&W						CSV
P-PK						LIM
						JPG
						ВМР
						Local

- Press the Save Type soft-key to select the file type you wish to save. In this example, we have selected the JPG image file type used to save screenshots.

- Press the Save soft-key to open the File Save dialog box. This will show you the file type and file name. You can use the front panel keypad to edit the file name.

SIGLENT

SIGLENT		2016-09-08 14:2	1:24			Ü	File	
LOG 10 dB	File						Browser Dir Fil	9
	U-disk0:/						Open/Load	
Free	Folder	File Name	Type Siz	ze	Date			
LgPwr Cont	local: free 80.37 MB +U-disk0: 236.00 KB/7.46 GB	System Volume Informa SSA_160908134153.jpg SSA_160908134204.jpg		в .80 кв .09 кв	2016-09-08 13:43:12 2016-09-08 13:41:54 2016-09-08 13:42:04		Back	
		SSA_160908134209.jpg SSA_160908134209.jpg SSA_160908140851.jpg	jpg 53.	.20 KB .79 KB	2016-09-08 13:42:10 2016-09-08 14:09:39		View Type All Type	•
A C&W		ave .jpg					Save Type JPG	•
Р-РК							Save	
	Pro	ess '+/-' to change input type.	Input type:	abc		l	JPG	
							Create Folde	•
							Operate	Þ
							Local	

- Press the Enter key on the front panel to save the file.



NOTE: The file type selected will also be mapped directly to the Save key located on the front panel. You can quickly open the file save dialog box by simply pressing Save once you have selected the file type.







North American Headquarters

SIGLENT Technologies NA 6557 Cochran Rd Solon, Ohio 44139 Tel: 440-398-5800 Toll Free:877-515-5551 Fax: 440-399-1211 info@siglent.com www.siglentamerica.com/

European Sales Offices

SIGLENT TECHNOLOGIES GERMANY GmbH Staetzlinger Str. 70 86165 Augsburg, Germany Tel: +49(0)-821-666 0 111 0 Fax: +49(0)-821-666 0 111 22 info-eu@siglent.com www.siglenteu.com

Asian Headquarters

SIGLENT TECHNOLOGIES CO., LTD. Blog No.4 & No.5, Antongda Industrial Zone, 3rd Liuxian Road, Bao'an District, Shenzhen, 518101, China. Tel:+ 86 755 3661 5186 Fax:+ 86 755 3359 1582 sales@siglent.com www.siglent.com/ens